

Pic. 4

MOUNTING AND MAINTENANCE INSTRUCTION






Fig. 5B – Bracket mounting



MOUNTING AND MAINTENANCE INSTRUCTION



Page 2 of 4


TALO 3_IM_ENG - Rev.05 of 15/07/15

Electrical line connection

To gain access to the electrical line, unlock the 3 closing hooks (A – Pic. 6) and lift the upper frame up to the action of the two hinges.


- **Luminaire with cable gland**: follow the directions in Pic. 8. Is strictly necessary tight the external sheet of the mains cable to the cable holder of the on-load switch
- **Luminaire with membrane**: follow the directions in Pic. 9. Is strictly necessary tight the external sheet of the mains cable to the cable holder of the on-load switch.


In case the luminaire is equipped with PLM device, before close the luminaire, annotate the serial number of the device.





MEMBRANE








MOUNTING AND MAINTENANCE INSTRUCTION




Page 3 of 4

Luminaire closure


To close the luminiare, follow the directive from Pic. 10 to Pic. 12.





Lift the upper frame

Е



Unlock the two hinges and move down the upper frame

LED modules extraction

- 1) Disconnect the LED connectors (C);
- 2) Loosen the screws (E) LED 3) Extract the
- modules.

LED module repositioning

- 1) Replace in the original position the LED modules;
- 2) Tighten the screws (E); 3) Connect LED the


connectors (C).

Gear tray extraction

- 1) Disconnect the mains connector (B)
- 2) Disconnect the LED connectors (C);
- 3) Loosen the 4 screws (D)
- 4) Extract the gear tray.

Gear tray repositioning

- 1) Replace in the original position the gear tray;
- 2) Tighten the 4 screws (D);
- 3) Connect the LED connectors (C);
- 4) Connect the mains connector (B).



SPD MAINTENANCE

The protection device is equipped with system that excludes power supply at the end of life of the luminaire.

If the luminaires switches-off when the system is still fed, the activity of the protection device should be checked looking at signaling LED.

To check this, use the appropriate tool asked to AEC Illuminazione.

LED ON _ Right functioning of the SPD




LED OFF _ End of life SPD, replace the SPD





MOUNTING AND MAINTENANCE INSTRUCTION





automatically release AEC Illuminazione Srl from any responsibility.